


NOTE:

TO EXTEND THE LIFE OF EXIT DEVICE, LOCK THE LATCH IN THE RETRACTED POSITION WHEN DOOR IS IN CONTINUOUS USE.





TO UNLOCK


HOLD PUSH RAIL DOWN. TURN DOGGING DEVICE CLOCKWISE WITH DOGGING KEY.


TO LOCK
HOLD PUSH RAIL DOWN. TURN DOGGING DEVICE
COUNTER CLOCKWISE WITH DOGGING KEY.


A-UL500XR Series RIM TYPE EXIT DEVICE
















- 1.REMOVE THE HEAD COVER AND THE SCREWS ON THE END COVER
- 2.ALIGN THE SCREW HOLES WITH THE HOLES ON THE DOOR
- 3.TIGHTEN THE SCREWS ON THE BODY AND THE LINING OF END COVER








- 1.CLOSE DOOR AND MARK LATCHBOLT ON DOOR JAMB WITH A PENCIL.
- 2.PLACE ROLLER STRIKE ON DOOR JAMB.
 ALIGN CENTER OF ROLLER STRIKE WITH
- ALIGN CENTER OF ROLLER STRIKE WITH CENTER OF PENCIL MARK. THEN ALIGN OUTSIDE EDGE OF ROLLER STRIKE WITH OUTSIDE EDGE OF DOOR JAMB.



- 3.MARK IN THE CENTER OF 2 ADJUSTABLE SLOT AND DRILL 7/32" PILOT HOLE AND 1/4"-20P THREAD AT MARKED LOCATIONS THEN TIGHTEN WITH 1/4"-20P FLAT HEAD SCREWS. OPEN AND CLOSE DOOR TO CHECK IF LATCHBOLT CAN EXTEND AND RETRACT PROPERLY. ADJUST ROLLER STRIKE IF NECESSARY.
- 4.WITH THE ROLLER STRIKE IN FINAL POSITION, DRILL AT THE CENTER 7/32" PILOT HOLE AND 1/4"-20P THREAD AND TIGHTEN WITH 1/4"-20P FLAT HEAD.





4. 1/4"-20P FLAT HEAD SCREW